

## Step Wedges

### ▶ Fluoroscopy Step Wedge

11 Step Wedge

Material: Aluminium

Overall dimensions: 132 x 50 x 35mm

Steps 12mm long x 50mm wide

Step 1: 5mm high

Other Steps: 3mm high

